

ADVANCED PROGRAMMING INSTRUCTIONS
Place and leave in machine for reference

CONFIGURE

ADVANCED

PASSWORD: 0

Password is 8700

MMC/SD

GROUP

SET GROUP PRICE

gr_PRICE: xx.xx

SETUP GROUP-PRI

g0_>>>SEL._ _

SETUP GROUP-SEL

g1_>>> SEL._ _

SETUP TIMEFRAME

tf_
tf_:g_
tf_:id_(0...7)
tf_:off_:_
tf_:on_:_

LED LIGHTS

PERC. DIMMING

PER.DIMMING: 0-100

TIME DIMMING

TIM. DIMMING: 0-100

CAMERA

SENSITIVITY

SENSITIVITY: 0-3

SET SINGLE VEND

SINGLE VEND: NO/YES

ANIMATION

ANIMATION TYPE

SLIDE/MOVIE

SLIDE DELAY

SLIDE DELAY: 10/15/20

ADVAN. MMC/SD

LOAD IMAGES

LOAD IMAGES: NO/YES

ERASE ONE IMAGE

xx/yy filename

ERASE ALL IMAGES

ERASE IMAGES: NO/YES

TUBE TOT. VALUE

TUBE VAL: _._

MACH DISABLE

DISABLE TIME #1

DISABLE: _ _ _ _ _
Monday, Tuesday, Wednesday
Thursday, Friday, Saturday
Sunday, Weekdays, Everyday

DISABLE TIME #2
Follow chart for
"DISABLE TIME #1"

DISABLE: _ : _ PM
Input standard time format.
Toggle AM/PM with any button
when flashing

DISABLE TIME #3
Follow chart for
"DISABLE TIME #1"

ENABLE: _ _ _ _ _
Monday, Tuesday, Wednesday
Thursday, Friday, Saturday
Sunday, Weekdays, Everyday

DISABLE TIME #4
Follow chart for
"DISABLE TIME #1"

ENABLE: _ : _ PM
Input standard time format.
Toggle AM/PM with any button
when flashing

DISABLE TIME #5
Follow chart for
"DISABLE TIME #1"

DISAB. CLEAR: NO
Toggle Yes/No with any button.
This will clear this machine
Disable/Enable setting.