




1.) Locate the crimp housing side of the existing kiosk validator harness that's plugged into the validator. Unplug this connection.




2.) Using a Phillips head, unscrew the two screws holding the negative and positive ends of the bill validator harness that are identified above. Now disconnect the old harness from the 24 volt battery.



3.) Plug the crimp housing end of the new validator harness into the port you previously removed the old one from in the bill validator.



4.) Identify the positive and the negative sides of the bill validator harness respectively. Connect the positive and negative ends into the proper location using the screws you previously removed with the Phillips head.



5.) Take the USB 3.0 cable included with the harness and plug it into the USB 3.0 port on the validator harness as shown.



6.) Plug the USB side of the USB 3.0 cable and plug it into the USB port on the USB hub.

Harness should now be fully installed